

## Daily Checkout

### Two-Hand control Device Operation

1. Turn the power switch ON and allow it to heat to temperature.
2. Turn the head switch to ON.
3. Place your left index finger into the left optical touch button.
4. Wait one or two seconds, then place your right index finger into the right optical touch button. The HEAD DESCENDING light should not turn on and the machine should not cycle.
5. Remove both hands from the optical touch buttons.
6. Place your index finger of your right hand into the right optical touch button.
7. Wait one or two seconds, then place your left index finger into the left optical touch button.
8. The HEAD DESCENDING light should not come on and the machine should not cycle.
9. Place your left index finger on the left optical touch button and your right index finger on the right optical touch button at the same time. The HEAD DESCENDING light should turn on and head should lower.

### True Dwell Operation

1. Turn power switch ON and allow it to heat to temperature.
2. Turn head switch ON
3. Place your left index finger into the left optical touch button and your right index finger into right optical touch button **at the same time**. The HEAD DESCENDING light should come on and the head should start descending.
4. Before the head lowers completely remove your right index finger from the right optical touch button. The HEAD DESCENDING light should turn off and the head should rise up.
5. Place your left index finger into the left optical touch button and your right index finger into right optical touch button at the same time. The HEAD DESCENDING light should come on and the head should begin lowering.
6. Before the head lowers completely remove your left index finger from the left optical touch button. The HEAD DESCENDING light should turn off and the head should rise up.
7. Place your left index finger into the left optical touch button and your right index finger into right optical touch button at the same time. The HEAD DESCENDING light should turn on and the head should start lowering.
8. Hold both fingers on the buttons until the head is completely lowered. Watch the HEAD TIMER lowered for the time set on THE HEAD TIMER.

# Daily Checkout Two-Hand control Device Operation

## Head Switch Operation

1. Turn the power switch ON and allow it to heat to temperature.
2. Turn the head switch to OFF.
3. Place your left index finger into the left optical touch button and your right index finger into the right optical touch button **at the same time**. The HEAD DESCENDING light should not begin lowering.
4. Turn Head Switch to ON.
5. Put your left index finger into the left optical touch button and your right index finger into the right optical touch button **at the same time**. The HEAD DESCENDING light should turn on and the head should begin lowering.

NOTE: If any of the above tests fail as described **DO NOT** operate the machine. Notify the person designated by your employer that the machine needs service.